

Week 5

Lecture 1

- Convection Heat Transfer. See Website for material on convective heat transfer.
- Overview of Convective Heat Transfer

Newton's Law of Cooling: $\dot{Q}_{conv} = h A (T_w - T_f)$

A is total convective area, T_w is surface temperature, T_f or T_∞ is fluid temperature, h is heat transfer coefficient whose units are $[W/m^2 \cdot K]$; h is complex parameter which depends on geometry, thermal and fluid properties, fluid flow and boundary conditions.

- Geometry: flat plate, circular cylinder, sphere, spheroids, other shapes; size, aspect ratio (thin or thick), orientation (vertical or horizontal).
- Type of flow: forced, natural or mixed (combination of forced and natural); laminar, turbulent (transitional); developing, fully-developed; steady or transient; internal or external; enclosure.
- Boundary condition: (i) isothermal wall ($T_w = \text{constant}$); or (ii) isoflux wall ($q_w = \text{constant}$).
- Type of fluid: viscous oil; water; gases (air); liquid metals.
- Fluid properties: symbols and units:
 mass density: ρ $[kg/m^3]$
 specific heat capacity: c_P $[J/kg \cdot K]$
 dynamic viscosity: μ $[N \cdot s/m^2]$
 kinematic viscosity: $\nu = \mu/\rho$ $[m^2/s]$
 thermal conductivity: k_f $[W/m \cdot K]$
 thermal diffusivity: $\alpha = k_f/(\rho c_p)$ $[m^2/s]$
 isobaric compressibility: β $[1/K]$.

All properties are temperature dependent. They are usually determined at the film temperature defined as the average of the wall temperature and the fluid

free stream temperature: $T_{film} = (T_w + T_\infty)/2$. Properties of many fluids: (gases, liquids and liquid metals) are presented in Handbooks and in Appendices in Text.

-
- Dimensionless Groups in Correlation Equations:
 - Prandtl number: $Pr = \nu/\alpha$ where $0 < Pr < \infty$;
 - Forced flow: Reynolds number: $Re = \rho U \mathcal{L} / \mu = U \mathcal{L} / \nu$
 - Peclet number: $Pe = U \mathcal{L} / \alpha = Re Pr$; U is a velocity scale, \mathcal{L} is a length scale.

-
- Natural convection: Grashof number: $Gr = g\beta(T_w - T_f)\mathcal{L}^3\rho^2/\mu^2 = g\beta(T_w - T_f)\mathcal{L}^3/\nu^2$
 - Rayleigh number: $Ra = Gr Pr = g\beta(T_w - T_f)\mathcal{L}^3/(\alpha \cdot \nu)$
 - Nusselt number: $Nu = h\mathcal{L}/k_f$
 - Stanton number: $St = h/(U \rho c_p) = Nu/(Re Pr)$.
 - Correlation equations for boundary layer flow:

- Forced Convection:
 $Nu = f(Re, Pr)$ or $Nu = C_w Re^m Pr^n$, C_w depends on geometry, type of flow, boundary condition and choice of \mathcal{L} , index m depends on type of flow (laminar or turbulent), index n depends on type of fluid and type of flow

- Natural convection:
 $Nu = f(Gr, Pr)$ or $Nu = C_w Ra^m Pr^n$; C_w depends on geometry, type of flow, boundary condition and choice of \mathcal{L} , index m depends on type of flow (laminar or turbulent), index n depends on type of fluid and type of flow.

- Diffusive Limit:
For small Reynolds and Grashof numbers, use the relation:
 $Nu = (Nu_{diffusion}^p + Nu_{BL}^p)^{1/p}$
 p is empirical parameter to give good agreement between correlation and data.

- Typical ranges of convective heat transfer coefficients. See material on Web site.

Lecture 2

Some Correlation Equations.

- Local $h(x)$ and average h heat transfer coefficients for forced, laminar flow over a plate.

- Average Heat Transfer Coefficient and Nusselt Number

$$h = \frac{1}{L} \int_0^L h(x) dx \quad \text{and} \quad Nu_L = \frac{hL}{k_f}$$

- Isothermal (UWT) Plate. $T_w = \text{const.}$ and $q_w = f(x)$.

$$\frac{h(x)x}{k_f} = c_w \left(\frac{Ux}{\nu} \right)^{1/2} \left(\frac{\nu}{\alpha} \right)^{1/3}$$

or as

$$Nu_x = \frac{0.3387 Re_x^{1/2} Pr^{1/3}}{[1 + (0.0468/Pr)^{2/3}]^{1/4}}$$

with restrictions: $100 < Re_x < 500,000$ for laminar flow, and all fluids: $0 < Pr < \infty$.

- For air ($Pr = 0.71$)

$$Nu_x = 0.291 Re_x^{1/2} \quad \text{and} \quad Nu_L = 0.582 Re_x^{1/2}$$

- Isoflux (UWF) Plate. $q_w = \text{const.}$ and $T_w = f(x)$.

$$\frac{h(x)x}{k_f} = c_w \left(\frac{Ux}{\nu} \right)^{1/2} \left(\frac{\nu}{\alpha} \right)^{1/3}$$

or as

$$Nu_x = \frac{0.4637 Re_x^{1/2} Pr^{1/3}}{[1 + (0.0205/Pr)^{2/3}]^{1/4}}$$

with restrictions: $100 < Re_x < 500,000$ for laminar flow, and all fluids: $0 < Pr < \infty$.

- For air ($Pr = 0.71$)

$$Nu_x = 0.404 Re_x^{1/2} \quad \text{and} \quad Nu_L = 0.808 Re_x^{1/2}$$

Lecture 3

- Simple, useful relations for air cooling.

- For UWT, laminar flow

$$h = 3.78\sqrt{\frac{U}{L}} \quad \text{at} \quad T_{film} = 300 \text{ K}$$

and

$$h = 3.88\sqrt{\frac{U}{L}} \quad \text{at} \quad T_{film} = 350 \text{ K}$$

Observe the relatively small difference in the coefficients 3.78 and 3.88 at these two film temperatures.

- Newton's Law of Cooling for UWT Plate of Area $A = LW$ at $T_{film} = 350 \text{ K}$.

$$\dot{Q}_{conv} = hA(T_w - T_\infty) = 3.888\sqrt{\frac{U}{L}}LW(T_w - T_\infty)$$

This is a convenient relation for many thermal analyses.

$$\dot{Q}_{conv} = f \times (\text{Power Dissipation}) \quad \text{where} \quad 0 < f < 1$$

- For UWF, laminar flow

$$h = 5.32\sqrt{\frac{U}{L}} \quad \text{at} \quad T_{film} = 300 \text{ K}$$

and

$$h = 5.30\sqrt{\frac{U}{L}} \quad \text{at} \quad T_{film} = 350 \text{ K}$$

Observe the very small difference in the coefficients 5.32 and 5.30 at these two film temperatures.

- Newton's Law of Cooling for UWT Plate of Area $A = LW$ at $T_{film} = 350 \text{ K}$.

$$\dot{Q}_{conv} = hA(T_w - T_\infty) = 5.30\sqrt{\frac{U}{L}}LW(\bar{T}_w - T_\infty)$$

where the average wall temperature is used:

$$\bar{T}_w = \frac{1}{L} \int_0^L T_w(x) dx$$

This is a convenient relation for many thermal analyses.

$$\dot{Q}_{conv} = f \times (\text{Power Dissipation}) \quad \text{where} \quad 0 < f < 1$$

- Reynolds Number at 300 K and 350 K

$$Re_L = \frac{UL}{\nu} = 62,850 UL \quad \text{at} \quad 300 K$$

and

$$Re_L = \frac{UL}{\nu} = 47,850 UL \quad \text{at} \quad 350 K$$

- Natural Convection from Vertical Isothermal (UWT) Plate. Laminar Flow.

$$\frac{hL}{k_f} = c_w \left(\frac{g\beta(T_w - T_\infty)L^3}{\nu^2} \right)^{1/4} \left(\frac{\nu}{\alpha} \right)^{1/4}$$

or in the compact form:

$$Nu_L = c_w Gr_L^{1/4} Pr^{1/4}$$

For gases $\beta = 1/T_\infty$. Alternative form of correlation equation is

$$Nu_L = c_w Ra_L^{1/4} \quad \text{where} \quad Ra_L = Gr_L Pr = \frac{g\beta(T_w - T_\infty)L^3}{\alpha\nu}$$

- Correlation Equation for UWT, Vertical Plate. Laminar Flow.

$$Nu_L = \frac{0.670 Ra_L^{1/4}}{[1 + (0.5/Pr)^{9/16}]^{4/9}}$$

with restrictions:

$$10^4 < Gr_L < 10^8 \quad \text{and} \quad 0 < Pr < \infty$$

- Simple, useful relations for UWT, Laminar Flow of Air at $T_{film} = 300 K$ and $T_{film} = 350 K$

$$h = 5.48 \left(\frac{T_w - T_\infty}{LT_\infty} \right)^{1/4} \quad \text{at} \quad T_{film} = 300 K$$

and

$$h = 5.45 \left(\frac{T_w - T_\infty}{LT_\infty} \right)^{1/4} \quad \text{at} \quad T_{film} = 350 K$$

Note the negligible difference in the coefficients for the two film temperatures.

- Newton's Law of Cooling for Vertical UWT Plate

$$\dot{Q}_{conv} = hA(T_w - T_\infty) = 5.45 \left(\frac{T_w - T_\infty}{LT_\infty} \right)^{1/4} LW (T_w - T_\infty)$$

This is a convenient relation for many thermal analyses. Note that:

$$\dot{Q}_{conv} = f \times (\text{Power Dissipation}) \quad \text{where} \quad 0 < f < 1$$

- Types of Forced and Natural Convection Problems which can be solved. Here are a few examples.

Given	Given	Given
T_w	\dot{Q}_{conv}	\dot{Q}_{conv}
T_∞	T_∞	T_∞
L	L	T_w
W	W	U
U	U	W
Find	Find	Find
\dot{Q}_{conv}	T_w	L