

Flow Work

Consider mass flow into a control volume through an inlet of constant cross-section during the time interval Δt .

Continuity Equation

The mass inflow into the CV during the time interval Δt is

$$\Delta M_{\text{in}} = \rho_{\text{in}} A_{\text{in}} \bar{V}_{\text{in}} \Delta t \quad [kg]$$

Flow Work

The flow work of the fluid entering the CV is defined as:

$$\Delta W_{\text{in}} = (\text{Force}) \times (\text{Displacement}) = (P_{\text{in}} A_{\text{in}}) \times (\bar{V}_{\text{in}} \Delta t)$$

Applying the continuity equation we have

$$\Delta W_{\text{in}} = \frac{P_{\text{in}} \Delta M_{\text{in}}}{\rho_{\text{in}}} = P_{\text{in}} v_{\text{in}} \Delta M_{\text{in}} = (P v \Delta M)_{\text{in}}$$

where $v = 1/\rho$. Similarly at the outlet we have

$$\Delta W_{\text{out}} = (P v \Delta M)_{\text{out}}$$

In general we can express the time rate of flow work out of the CV as

$$\dot{W}_{\text{out}} = \iint_A P v \rho \vec{V} \cdot \vec{n} dA$$

Net Inflow Rate of Energy and Work Into CV

The energy and work associated with mass flow across control surfaces can be determined from the following general expression:

$$\dot{E}_{\text{CV}} + \dot{W}_{\text{CV}} = - \iint_{\text{CS}} (e + P v) \rho \vec{V} \cdot \vec{n} dA$$